

Massage Cushion

Instruction Manual



Keep the instructions properly for future reference.

Precautions

1. To keep the best performance, please run out of battery before first charging, full charging is 6-8 hours and over-charging more than 10 hours is not recommended.
2. Please don't use it more than two hours for one time.
3. In case of short cut or fire accident, please keep away from fire, water or any fluid. Store under high temperature is forbidden.
4. If cleaning, please wipe with disinfected cotton soaked in natural detergent. Be careful when you take off cushion cover and wash it. Switch is connected with cover, cleaning with water for pillow core is prohibited.
5. Pregnant women is prohibited.
6. Massage cushion is for leaning on or rest, don't put heavy objects on it.
7. In case of any unusual conditions or uncomfortable feels in operation, please stop using it and check without power.

Main Features

- Pressure-sensing massage: When you press against the massage pillow, it starts working.
- Cordless massage with built-in rechargeable Lithium battery, 5V type-C charging port.
- Vibrating massage for all parts of your body to release fatigue. It can also improve digestion when it is applied for abdomen massage.
- It is portable (425g only), it can be used in the car, in office and at home.
- It comes with high density sponge to provide great support for your body.



At Home




In the Car



In Office



Traveling



How to Operate

1. Lean on the cushion to start massage automatically, you can press ON/OFF switch to stop massage anytime, press this switch again it will resume to massage. Circularly press this button can also select different intensities.
2. When you leave the cushion, it stops automatically.
3. It can be applied to all parts of your body for relaxing massage.
4. It comes with a type-C USB cable. Connect this cable to any USB port such as computer, adapter, or power bank for charging.

Notes:

- ! Do not set up or use the massager in bathroom or similarly wet/damp areas, as such an environment may reduce the lifespan of the massager mechanism.
- ! Ensure the massager is not exposed to direct sunlight, or placed near heaters and other heat sources.

Maintenance

- Switch off before cleaning.
- Clean only with a soft, slightly damp sponge. Never allow the unit to become wet.
- Do not immerse in any liquid to clean.
- Never use abrasive cleaners, brushes, gasoline, kerosene, glass/ furniture polish or paint thinner for cleaning of this product.
- Do not use chemicals or abrasive cleaners to clean the outside of the massager as these chemicals may damage the material.
- Do not use your massager if it has malfunction. Or has been damaged in any way, have the appliance inspected by a qualified person, don't disassemble it yourself.

Guarantee

This product is guaranteed for 12 months from the date of the original purchase. If any defect arises due to faulty materials or workmanship the faulty products must be returned to the place of purchase. Refunds or replacement is at the discretion of the store.

The following conditions apply:

1. The product must be returned to the retailer with the original proof of purchase.
2. The product must be installed and used in accordance with the instructions contained in this instruction guide.
3. It must be used only for domestic purposes.
4. It does not cover wear and tear, damage, misuse or consumable parts.

Technology Parameters

Desc.: Massage Cushion

Rated Voltage: DC5(V)

Rated Power: 0.8(W)

Battery Capacity: 2200(mA)

Product Size: 30x30x9cm

Product Weight: 425g