

Framed Sensory Dark Den Cube Tent

SKU: DDN199NGE

Please read the Information for Use carefully before first use. This Information for Use contains necessary safety advice and instructions. Retain this Information for Use for future reference.

WARNINGS:



Keep away from fire



Adult supervision required

Important:

- Age 3 years+
- The assembly and storage of the Dark Den Cube Tent should always be carried out by a responsible adult.

Contents:

- Black Dark Den Cube Tent Outer x 1
- Poles x 12.
- Connectors x 8.
- Storage Bag x 1

How to assemble:

1. Check the contents and ensure all parts are present and correct.
2. Sort the parts out ready for assembly.
3. Starting at the top of the Dark Den Cube Tent, slide the poles into the sleeves.
4. Connect the poles with the corner connectors.
5. Repeat Step 2 and Step 3 for the base of the Dark Den Cube Tent.
6. Insert the remaining poles through the sleeves in the sides of the Dark Den Cube Tent and into the corresponding connectors.
7. Your Dark Den Cube Tent is now ready to use.

Care instructions:

The Dark Den Cube Tent cover is made from 100% nylon and has a 100% polypropylene frame.

- Wipe clean with a damp cloth.
- Do not use abrasive or chemical solutions.
- Ensure fabric is dry before storage.



Made in China

Imported by Bing International Ltd, Unit 14 Elgar Business Centre, WR2 6NJ on behalf of
Sensory Direct (UK) Ltd, Unit 65c, Blackpole Trading Estate West, Worcester, WR3 8TJ, UK.
www.sensorydirect.com