

Wobble Cushions

SKU: RDS05SMA / RDS35GRN

Please read the Information for Use carefully and retain for future reference.

WARNINGS:



Adult supervision required



Contains small parts - choking hazard



Do not exceed the maximum weight limit



This product is not a toy

Important:

- Maximum weight limit – 200kg.
- It is recommended that the Wobble Cushion is used for a maximum of 30 minutes at any one time. Can be used at regular intervals throughout the day.
- **DO NOT OVER INFLATE** the Wobble Cushion.

Good to know:

Junior Wobble Cushion

- Dimensions – Diameter: 30cm.
- Made from PVC - Free from BPA, Latex, Rubber and Phthalates.
- Fitted with a white plastic stopper for inflation.

Senior Wobble Cushion

- Dimensions - Diameter: 35cm.
- Made from TPE - Free from BPA, Latex, Rubber and Phthalates.
- Fitted with a valve for inflation.

Inflating and deflating the Wobble Cushions:

Junior Wobble Cushion

- To inflate the Wobble Cushion, remove the white plastic stopper from the back of the cushion and blow up by mouth or using a hand pump (not included). Once the required inflation is reached replace the white plastic stopper firmly.
- To deflate the Wobble Cushion, remove the white plastic stopper.

Senior Wobble Cushion

- The Wobble Cushion can be inflated by using the mouth or by using a pump with a needle adaptor (not included).
- If you wish to inflate the Wobble Cushion by mouth, ensure you pop out the valve before you start or alternatively insert the need adaptor into the valve and inflate using the pump. Once the required inflation is reached, slowly remove the needle adaptor. The Wobble Cushion will remain inflated.
- To deflate the Wobble Cushion, insert the needle adapter (without the pump) and let the air escape out of the valve.

Made in Taiwan

Sensory Direct (UK) Ltd, Unit 65c, Blackpole Trading Estate West, Worcester, WR3 8TJ, UK.
www.sensorydirect.com