

Bubble Tube – 60cm

SKU: MNG60BUB

Please read the Information for Use carefully before first use. This Information for Use contains necessary safety advice and user instructions, follow the instructions on how to operate. Retain this Information for Use for future reference.

Contents in the box:

- | | |
|---|---|
| ❶ Lid | ❷ Base Plates x 2 |
| ❸ Tube | ❹ Power Cable and Adaptor |
| ❺ Base Unit (including 4 x Screws for assembly) | ❻ Pack of small decorative balls and fish |

Before you begin:

- Inspect the tube to make sure that there are no cracks or damage. Take extreme caution when handling, as the tube is a fragile product.
- Check the contents and ensure all items are present and correct.
- Keep all packaging until after a successful installation.

WARNINGS:



Adult supervision required



This product is not a toy

THE SUPERVISION OF AN APPROPRIATE ADULT IS REQUIRED AT ALL TIMES.

DO NOT LEAVE UNATTENDED WHILST IN USE.

Important:

- Ensure the Bubble Tube is situated on a flat, stable surface and in a location where it does not present a hazard and cannot be knocked over.
- We recommend using distilled water as the Bubble Tube will stay clean for longer. Tap water may cause water discolouration.
- Do not operate with hot or ice-cold water.
- Do not lift, carry or pull the Bubble Tube by the power cable.
- Do not attempt to move the Bubble Tube when filled with water.
- Not suitable for live fish.
- Switch OFF the mains power socket when not in use.
- Disconnect and drain the water if storing away for an extended period.
- If the power cable or unit are damaged, discontinue use immediately.
- Only use with the power cable and adaptor supplied.
- This Bubble Tube is suitable for INDOOR USE only.

Good to know:

- The Bubble Tube requires approximately 1.3 litres of water to fill to the recommended level.
- The flow rate of the bubbles cannot be adjusted.
- The LED bulbs are non-replaceable.

Information for Use


- The Bubble Tube is not touch reactive.
- Some noise and vibration from the Bubble Tube is expected. Those very sensitive to noise may find the noise and vibration from the Bubble Tube triggering.

Specification:

Power:	Input Output	100-240V – 50-60Hz 5V DC 1000mA
Dimensions:		(H) 60cm x (Dia.) 6cm
Material:		PETG
WARNING: DO NOT open the Unit. There are no user serviceable parts inside.		

Installation and operation:

- Ensure the Bubble Tube is situated on a flat, stable surface and in a location where it does not present a hazard and cannot be knocked over.
- Align the screw holes on the two base plates and securely screw them together using the 4 screws provided. (Fig. 1).
- Fit the base unit to the tube. (Fig 2.)
- Remove the lid and fill the Bubble Tube with water (preferably distilled water), leaving approximately 3cm of space.
- Insert the small decorative balls and fish (if desired).
- Replace the lid.
- Plug the power cable into the base unit and plug the adaptor into the wall. Switch on the mains power socket. Ensure the power cable is routed so it does not present a trip hazard.



Care instructions:

- Always unplug the Bubble Tube from the mains power socket before cleaning and handling.
- To clean the surface, wipe gently with a soft cloth.
- To clean the inside, use a cloth with warm soapy water. Rinse the Bubble Tube thoroughly to remove all soap residue, then refill with fresh water.
- Do not use abrasive cleaners or tools that could scratch the Bubble Tube.
- Do not use bleach or other harsh chemicals.
- Periodically inspect the Bubble Tube for leaks.

Troubleshooting:

- **Tube is cracked:** If the tube is cracked, please contact us for assistance.
- **Power Cable not working:** If the power cable is damaged, please contact us for assistance as the power cable is only available from the manufacturer.
- **Water appears cloudy or green:** Add a small amount of algacide (not included). Consider replacing the water if it has been in the Bubble Tube for more than 4-6 weeks. Clean the interior of the Bubble Tube if needed.

Warranty information:

- Our Bubble Tubes are made with the highest quality materials. In the event that a Bubble Tube does not have our usual standard of excellence, we will repair or replace it, at our discretion, within 12 months from the date of purchase.
- A valid proof of purchase, with the purchase date clearly indicated, must be provided.
- Photos of defective Bubble Tubes may be required to help us evaluate the cause of the defect.

Water damage:

- This Bubble Tube is not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within the Bubble Tube will cause damage and is not covered under the warranty.
- The use of "hard water" and/or caustic cleaners can affect the finish of the Bubble Tube.
- Failure to keep the unit clean, and use of additives/cleaners, will also void the warranty.

Not covered under the warranty:

- The warranty will NOT cover cases of damage due to inadequate care, and/or neglect, immersion in water or improper installation, storage or maintenance.
- This warranty will NOT cover damage by accident, misuse, negligence or if modifications have occurred.
- This warranty does NOT cover any additional charges for installation, removal, disposal, shipping costs or consequential damage associated with any warranty claim.

**UK
CA**

Made in China



Imported by Bing International Ltd, Unit 14, Elgar Business Centre, WR2 6NJ on behalf of Sensory Direct (UK) Ltd, Unit 65c, Blackpole Trading Estate West, Worcester, WR3 8TJ, UK.
www.sensorydirect.com