

## LED Interactive Light Column – 180cm

SKU: HTS22BNG

**Please read the Information for Use carefully** before first use. This Information for Use contains necessary safety advice and user instructions, follow the instructions on how to operate. Retain this Information for Use for future reference.

### Contents in the box:

- |                                |                           |
|--------------------------------|---------------------------|
| ❶ LED Interactive Light Column | ❸ 4A 12V AC Power Adaptor |
| ❷ Cross-shaped Base Plates x 4 | ❹ Remote Control          |

### Before you begin:

- Unpack the contents of the box carefully and check that all items listed above are present and correct.
- Inspect the LED Interactive Light Column to make sure that there are no cracks or damage. Take extreme caution when handling, as the LED Interactive Light Column is a fragile product.
- Keep all packaging until after a successful installation.

### WARNINGS:



Adult supervision required



Keep batteries away from children



This product is not a toy

THE SUPERVISION OF AN APPROPRIATE ADULT IS REQUIRED AT ALL TIMES.

DO NOT LEAVE UNATTENDED WHILST IN USE.

### Important:

- Before first use, check that all the screws are tightened and the base is stable to prevent tipping.
- Always ensure the rocker switch is in the OFF (0) position when connecting or disconnecting the power adaptor.
- Ensure the LED Interactive Light Column is situated on a flat, stable surface and in a location where it does not present a hazard and cannot be knocked over.
- Do not lift, carry or pull the LED Interactive Light Column by the power adaptor.
- Switch OFF at the mains power socket when not in use.
- The remote control contains a coin battery which can cause severe or fatal injuries in as little as two hours if it is swallowed or placed inside any part of the body. If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention.
- If the power adaptor is damaged, discontinue use immediately.
- Only use the power adaptor provided. Using an incorrect adaptor may damage the product.
- This LED Interactive Light Column is suitable for INDOOR USE only.

### Good to know:

- Features seven colour gradients.
- Responds to music and sound in real-time.
- Translates music, beats, and ambient sounds into a captivating, synchronised display of coloured lights.

## Specification:


Dimensions: LED Interactive Light Column Base	(H) 180cm x (Dia.) 15cm (W) 50cm
Material:	Acrylic

## Installation and operation:

- **Assemble the base:**
  - Lay the LED Interactive Light Column carefully on its side on a soft, protected surface. Take one cross-shaped base plate and align it with the screw holes on the bottom of the column. Use the provided screws to firmly attach the plate.
  - Repeat the process for the remaining three plates, one by one until a complete, stable cross is formed.
- **Connect to power:**
  - Once the base is attached, carefully stand the LED Interactive Light Column upright on a flat, stable surface.
  - Locate the DC power jack and the rocker switch (ON/OFF) on the column. Ensure the rocker switch is in the OFF (0) position before connecting the power adaptor. Connect the power adaptor to the column's DC power jack.
- **Power on:**
  - Plug the power adaptor into the mains power socket. Turn the rocker switch to the ON (I) position. The column will illuminate, indicating it is ready for use.
- **Control your lights:**
  - You can operate the LED Interactive Light Column using the provided remote control

## Remote control functions:

- (1) **Power button:** Turns the LED Interactive Light Column on and off.
- (2) **Colour -/+:** Decreases or increases the colour intensity or hue.
- (3&4) **Brightness -/+:** Decreases or increases the light brightness.
- (5&6) **Mode -/+:** Changes built-in modes between colour change / colour gradient / timing of light changes. Minus (-) will return to previous setting. Plus (+) will move to the next setting.
- (7&8) **Sound Speed -/+:** Decreases and increases the speed of the sound-related effects.
- (9) **Music Mode -/+:** Activates sound mode. There are 30 different visual light settings that respond to sound, adjusted by using the minus (-) or plus (+) button. Sound activation mode will only cease once another function button is pressed. Please note this mode synchronises lighting or effects with music – it does not play music.
- (10) **Auto Menu:** Activates auto mode where the light function will automatically change between colours and gradients of colour on a preset setting.
- (11) **Fixed colour selection:** Selects a preset fixed colour option.



## Care instructions:

- Always unplug the adaptor from the mains power socket before cleaning and handling.
- Wipe gently with a soft, dry cloth. Do not use abrasive cleaners or tools that could scratch the acrylic. Do not use bleach, solvents or chemicals.
- Inspect the power adaptor and cable regularly for any signs of damage.
- Periodically check that all screws in the base plates are tight to ensure structural stability.
- When not in use for an extended period, store the LED Interactive Light Column in a cool, dry place away from direct sunlight and dust.

## Troubleshooting:

- **LED Interactive Light Column does not light up:**
  - Check power connection to ensure the power adaptor is firmly plugged into both the LED Interactive Light Column DC power jack and the mains power socket.
  - Ensure the rocker switch on the column is in the ON (I) position.
  - Check the mains power socket is working by testing with another device.
- **No response to music:**
  - Check microphone settings using the remote control to ensure the microphone is not muted or set to low sensitivity level.
  - Make sure the LED Interactive Light Column is not in static colour mode.
  - Check audio source to ensure the music or sound source is loud enough and placed close enough for the LED Interactive Light Column's microphone to pick up.
- **Remote control not functioning:**
  - Check the battery is installed correctly.
  - If installed correctly and the remote is still not working, replace the battery.
- **LED Interactive Light Column is unstable:**
  - Turn off the power at the mains power socket and check that all screws connecting the cross-shaped base plates to the column are fully tightened.
- **Power adaptor is overheating:**
  - Use the correct adaptor. Disconnect the power adaptor immediately.
  - Only use the power adaptor provided with the LED Interactive Light Column.

**UK  
CA**

Made in China



Imported by Bing International Ltd, Unit 14, Elgar Business Centre, WR2 6NJ on behalf of  
Sensory Direct (UK) Ltd, Unit 65c, Blackpole Trading Estate West, Worcester, WR3 8TJ, UK.  
[www.sensorydirect.com](http://www.sensorydirect.com)