

## Ear Defenders

SKU: EDC01BLU / EDC02DKB / EDC03RED / EDC04LIM / EDC05PIN / EDC06BLK

---

### WARNING:

- Adult supervision required (when worn by children).

### Important:

- Suitable for ages 12 months+
- Compliant with EN 352-1:2020 (Hearing protections. General requirements – Earmuffs).
- SNR 27dB, NRR 21dB.

### Care and maintenance instructions:

- Clean with warm soapy water. Do not use abrasive substances or solutions. The Ear Defenders can be disinfected with a solution very low in alcohol.
- Store out of direct sunlight, away from chemicals and abrasive substances or solutions. Pads may deteriorate with use and should be examined at frequent intervals.

### How to use:



Open the headband and pull the ear cups apart and place over the ears so that the cushions form a snug seal around the ears. (Fig. 1).



Settle the headband in a position on the head whilst adjusting the height of the ear cups until they feel comfortable and the headband rests on top of the head to support the cups. (Fig. 2).



The ear cups should fit snugly against the head. To ensure an effective noise seal, adjust the ear cups and headband to the correct position on the head. Put the Ear Defenders on before exposure to noise. (Fig.3).

It is recommended that the Ear Defenders are fitted, adjusted and maintained in accordance with the manufacturer's instructions and are regularly inspected for serviceability.



Made in China

Imported by Bing International Ltd, Unit 14 Elgar Business Centre, WR2 6NJ on behalf of  
Sensory Direct (UK) Ltd, Unit 65c, Blackpole Trading Estate West, Worcester, WR3 8TJ, UK.  
[www.sensorydirect.com](http://www.sensorydirect.com)