

Ear Defenders

SKU: EDC01BLU, EDC02DKB, EDC03RED, EDC04LIM, EDC05PIN, EDC06BLK

Please read the Information for Use carefully before first use. This information for Use contains necessary safety advice and user instructions. Please retain for future reference.

WARNINGS:



Adult supervision
required
(when worn by children)

Important:

- Suitable for age 12 months+
- Compliant with EN 352-1:2020 (Hearing protections. General requirements – Earmuffs).
- SNR 27dB, NRR 21dB.
- Check before use, discontinue using if showing signs of wear and tear.

Good to know:

- Dimensions – Opened: (H) 17cm x (W) 13cm; Folded: (H) 10cm x (W) 12cm.
- Weight – 0.2kg.

How to use:



Open the headband and pull the ear cups apart and place over the ears so that the cushions form a snug seal around the ears. (Fig. 1).



Settle the headband in a position on the head whilst adjusting the height of the ear cups until they feel comfortable and the headband rests on top of the head to support the cups. (Fig. 2).



The ear cups should fit snugly against the head. To ensure an effective noise seal, adjust the ear cups and headband to the correct position on the head. Put the Ear Defenders on before exposure to noise. (Fig.3).

Care and maintenance instructions:

- Clean with warm soapy water. Do not use abrasive substances or solutions.
- The Ear Defenders can be disinfected with a solution very low in alcohol.
- Store out of direct sunlight, away from chemicals and abrasive substances or solutions.
- Pads may deteriorate with use and should be examined at frequent intervals.
- It is recommended that the Ear Defenders are fitted, adjusted and maintained in accordance with these instructions and are regularly inspected for serviceability.



Made in China